Heatmax Trading LLCArray

CRICUT MAKER DEBOSSING TIP WITH QUICKSWAP HOUSING

Main category: PRODUCT FROM ODOO


Cricut Maker Debossing Tip with QuickSwap Housing

Product code	093573840999
Price	185
Base price	185
List price	0
Amount	4
Weight	0.000
Height	0
Width	0
Length	0
Return period	10

FULL DESCRIPTION

Add professional polish and elevated elegance to paper crafts. To create crisp, detailed debossed designs, just snap this tip onto the QuickSwap Housing and tell your Cricut Maker to "Go!" Unlike folders, which lock you into a specific design, this rolling debossing ball, with a wider range of motion, gives you free reign to customize, personalize, and design with incredible intricacy. Make a dimensional wedding card, thank you card with your monogram, or add flourish to gift boxes, tags, and more. Creates a stunning effect on foil cardstock, coated paper, shimmer and glitter paper, foil cardstock, and much more. For use with Cricut Maker machines. Expand your collection of Cricut Maker tools with a variety of QuickSwap tips. Just swap out Fine Debossing Tip with any other QuickSwap tip, including Engraving Tip, Wavy Blade, Scoring Wheels, and Perforation Blade â€“ with more on the way.

FEATURES